



---

🌍 Before the cleansing, the anilox roller is to wet with water (for water-based inks) or with solvents (for solvent-based inks). Then apply Böttcherin CREME as even film on the roller surface (consumption approx. 100/g/m<sup>2</sup>)

Allow to take effect for one hour. After that clean the surface with water or solvent and a brush. All residuals are to remove completely.

*Note*

🌍 Wear suitable protective gloves and safety eyewear during the use!

---

🌍 Pouch 1kg

🌍 Box with 4 x 1kg

*Package*