

Anwendungs-Leitfaden

Laktücher und Lackplatten

Vollflächen-Lackierung:

⊕ BT 1003 (1.15 mm)	✓	⊕ BT 1004 (1.15 mm)	✓
⊕ BT 1003 (1.35 mm)	✓	⊕ BT 1005 (1.35 mm)	✓
⊕ BT 1002 (1.95 mm)	✓	⊕ BT 1008 (1.15 mm)	✓
⊕ BT 1007 (1.95 mm)	✓		

Spot-Lackierung:

⊕ BT 1003 (1.15 mm)	✓	⊕ BT 1004 (1.15 mm)	✓
⊕ BT 1003 (1.35 mm)	✓	⊕ BT 1005 (1.35 mm)	✓
⊕ BT 1002 (1.95 mm)	✓	⊕ BT 1008 (1.15 mm)	✓
⊕ BT 1007 (1.95 mm)	✓		

Dispersionslackierung

⊕ BT 1003 (1.15 mm)	✓	⊕ BT 1004 (1.15 mm)	✓
⊕ BT 1003 (1.35 mm)	✓	⊕ BT 1005 (1.35 mm)	✓
⊕ BT 1002 (1.95 mm)	✓	⊕ BT 1008 (1.15 mm)	✓
⊕ BT 1007 (1.95 mm)	✓		

Standard UV-Lackierung:

⊕ BT 1003 (1.15 mm)	~	⊕ BT 1004 (1.15 mm)	✗
⊕ BT 1003 (1.35 mm)	~	⊕ BT 1005 (1.35 mm)	✗
⊕ BT 1002 (1.95 mm)	✓	⊕ BT 1008 (1.15 mm)	✓
⊕ BT 1007 (1.95 mm)	✓		

Hochglanz UV-Lackierung:

⊕ BT 1003 (1.15 mm)	~	⊕ BT 1004 (1.15 mm)	✗
⊕ BT 1003 (1.35 mm)	~	⊕ BT 1005 (1.35 mm)	✗
⊕ BT 1002 (1.95 mm)	~	⊕ BT 1008 (1.15 mm)	✓
⊕ BT 1007 (1.95 mm)	~		

Große erhabene Flächen:

⊕ BT 1003 (1.15 mm)	✓	⊕ BT 1004 (1.15 mm)	✓
⊕ BT 1003 (1.35 mm)	✓	⊕ BT 1005 (1.35 mm)	✓
⊕ BT 1002 (1.95 mm)	✓	⊕ BT 1008 (1.15 mm)	✓
⊕ BT 1007 (1.95 mm)	✓		

Kleine erhabene Flächen:

⊕ BT 1003 (1.15 mm)	~	⊕ BT 1004 (1.15 mm)	✗
⊕ BT 1003 (1.35 mm)	~	⊕ BT 1005 (1.35 mm)	✗
⊕ BT 1002 (1.95 mm)	✓	⊕ BT 1008 (1.15 mm)	✓
⊕ BT 1007 (1.95 mm)	✓		

✓ = geeignet

~ = bedingt geeignet

✗ = ungeeignet

